

**PT100
TEMPERATURE HEAD
TRANSMITTER
THP101**



INSTALLATION GUIDE

IG_INHD_THP101_E02A

PT100 TEMPERATURE HEAD TRANSMITTER THP101

INSTALLATION GUIDE

Table of contents

step
01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER

Pages 3 to 9

step


01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER

DOWNLOAD AND INSTALL "TEKON CONFIGURATOR" FREE SOFTWARE FROM TEKON ELECTRONICS WEBSITE


01

Connect the THP101 transmitter to the SARC2 cable configurator.



02

Connect the PT100 probe to the THP101 transmitter.



03

Connect the SARC2 configurator cable to the computer.



04

Open Tekon Configurator software.




step
01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER

06

Load the "Port COM" corresponding to the THP101.




NOTE:

If the USB cable has already been connected before opening the device page, "Port COM" will appear in the list, otherwise you need to click on the "🔍" button.

07

Select corresponding *Port COM*².




² You can check device's serial port name in "Device Manager" on Microsoft® Windows® operating system.

step
01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER

08


Click on *Connect* () button.



NOTE:

For security reasons, it is only allowed to change the settings during the first 60 seconds after power up.

The software will connect to the device.



NOTE:


If the software is unable to connect to the device, the  status is displayed. If it hasn't connected, go back to the previous steps and check the port COM.

step
01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER


09

When the software connects to the device, the “*Connected*” message will be displayed.



10

While the THP101 transmitter it is in configuration mode, the blue led will flash continuously.




step

01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER

11

To change the default settings, update the value of the desired parameter and select the “Write Device” option. In this example, we change the “Temperature Min.” to 0 and “Temperature Max.” to 200.



NOTE:

The “WRITE DEVICE” button will only be active when there is a change to one of the editable fields, if there is no change it will be disabled.

While the settings are being written, the following icon will be displayed next to the “WRITE DEVICE” button ()

If the changes to the device have been written, the following symbol will appear ()


If not, the following symbol will appear (), try again and check that the device is connected correctly.

step
01

CONNECT AND CONFIGURE THP101 TEMPERATURE HEAD TRANSMITTER

12

Click on  to read the current temperature value.




Wait for the software to read the values from the device. Wait for the  status to change to .

If the device reading fails  appears. Make sure that all the steps have been carried out correctly.

13


Click on the button  to exit *configuration mode* and return the device to normal operating mode.



TEKON ELECTRONICS
a brand of Bresimar Automação S.A.

Quinta do Simão
3800-230 Aveiro
PORTUGAL

P.: +351 234 303 320
M.: +351 933 033 250
E.: sales@tekonelectronics.com



Cofinanciado por:



UNIÃO EUROPEIA
Fundo Europeu
de Desenvolvimento Regional