



# DUOS inAIR WIRELESS TRANSMITTER INSTALLATION GUIDE

IG\_DUOS\_INAIR\_E01A

# DUOS inAIR TRANSMITTER

## INSTALLATION GUIDE

### Table of contents

step  
**01**

**CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY**

Pages 4 to 11

---

step  
**02**

**CONNECT AND CONFIGURE DUOS WIRELESS inAIR TRANSMITTER**

Pages 12 to 17

---

step  
**03**

**CHECK WIRELESS COMMUNICATION BETWEEN DUOS inAIR AND GATEWAY**

Page 18

---

# DUOS inAIR TRANSMITTER

## INSTALLATION GUIDE

### Table of contents

step  
**04** **CONNECT AND CONFIGURE DUOS WIRELESS REPEATER**  
Pages 19 to 25

---

step  
**05** **CONNECT DUOS WIRELESS IOT GATEWAY**  
Pages 26 to 39

---

#### LEGEND:



Important information for the setup;



Take note of the information;



Validation of a setting;

step

**01**


CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY



**NOTE:**

If your device is a DUOS IoT GATEWAY, please consider the information on this page. If your device is a DUOS GATEWAY, please go to the next page to start the equipment setup.

SYSTEM ARCHITECTURE



MINIMUM REQUIREMENTS

The right application of DUOS IoT GATEWAY only occurs if all minimum requirements are met by the customer side. The architectural minimum requirements needed to successfully use this device are:

- **Ethernet cable** (included with your DUOS IoT GATEWAY);
- **DHCP server;**
- **Web browser with the latest version;**

You must have a DHCP server in your network. The main purpose of this kind of server is to automatically provide and assign IP addresses and other network parameters to connected devices.

To begin the configuration of DUOS IoT GATEWAY, the pin of button mode, must be in the *Config Mode* side.

After completing the setup procedures, go to [step 5](#) to begin the connection to the platform.



step  
**01**

CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY

*TEKON CONFIGURATOR SOFTWARE* is only compatible with the Microsoft Windows Operating System.

**01** Connect the antenna to the *Gateway*.



**02** Connect the *DUOS RS485-USB* cable to the computer and then to the Gateway.



**03** Check the device connection through the LED signage.  
If the red and blue LEDs are active, both the cable and *Gateway* are working correctly.

- LED flashes slowly
- 1** — LED switched on and steady
- 2** --- Red LED flashes every second whenever it sends beacons to new elements to join the network

Green LED flashes as soon as the device receives data from other equipment.

10 Seconds to enter configuration mode


step

**01**

CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY

**04**


Open *Tekon Configurator Software*<sup>1</sup> and select from the menu *DUOS >> Gateway >> Configuration*



**05**

Select the Serial Port of the *DUOS Wireless Gateway*

Click on the *Refresh Serial Ports* button.



<sup>1</sup> Tekon Configurator software is free of charge and available at [www.tekonelectronics.com](http://www.tekonelectronics.com)


step

**01**

CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY

**06**

Select the *Port name*<sup>2</sup> of the device.



**07**

Remove the *DUOS RS485-USB* cable from the *Gateway* side and reinsert it.



**NOTE:**



After reinserting the cable, you have 10 seconds to enter in configuration mode by clicking on the Connect (  ) button, while the blue LED flashes slowly. In this mode, you can manage the device parameters: *Modbus Address*, *Modbus baud rate*, *Modbus Parity*, *Wireless Network ID* and *Wireless Channel*.

<sup>2</sup> You can check the device port name in the Device Manager menu in the Windows operating system.

step



**01**

CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY

**08**

Click on the *Connect* (🌐) button to enter configuration mode.

The status string at the bottom of the software window gives feedback of reading operations, as well as the *Gateway* LED indication.



- LED flashes slowly
- LED flashes quickly
- 1** — LED switched on and steady



**NOTE:**


When 10 seconds have been exceeded, the blue LED is steady and it is no longer possible to enter configuration mode. In this case, the cable must be removed and reinserted - step 2.

step  
**01**

CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY

**09**

Take note of the device configuration data available, namely: *Modbus Address*, *Modbus Baudrate*, *Modbus Parity*, *Wireless Network ID* and *Wireless Channel*.




**NOTE:**

The wireless network connection between devices is ensured by the *Wireless Network ID* and *Wireless Channel* field parameters.

**10**

Click on the *Disconnect* (🔌) button.

The Modbus interface and the wireless network are active if the blue LED is on and steady and the red LED is flashing once per second.




step  
**01**

CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY


**11**

**Modbus Communication**

Open the *Modbus* tab of the *Gateway* and set the previously saved configurations.



Ensure that the *Port name*, *Baudrate*, *Parity* and the *Modbus Address* fields are the same obtained in configuration mode.




- LED switched on and steady
- 1** → Red LED flashes every second whenever it sends beacons to new elements to join the network.

step  
**01**

**CONNECT AND CONFIGURE DUOS WIRELESS GATEWAY**

**12**

Click on the *Connect* (🌐) button and check the operation status at the bottom of the window.



The messages *Connected to Modbus* and *Reading successfully* will appear if the *Serial Port* configuration parameters are correct and the Modbus connection established.  
If the blue LED is on and steady and red LED flashes once per second, the *Gateway* is fully operational on the Modbus and wireless interfaces.

step

# 02

## CONNECT AND CONFIGURE DUOS inAIR WIRELESS TRANSMITTER


**01**

Prepare the *DUOS inAIR Wireless Transmitter*.  
Unscrew the connector's rubber plug.



**02**


Open a new window of the *Tekon Configurator Software* and select the menu *DUOS >> Transmitter*.



**03**

Connect the *DUOS TRANSMITTER SARC* cable to the computer and then to the transmitter.


After cable connection, all LEDs stay active during 10 seconds.



step

02


CONNECT AND CONFIGURE DUOS inAIR WIRELESS TRANSMITTER



LED switched on and steady

04

Click on the *Refresh Serial Ports* button.




step

**02**

CONNECT AND CONFIGURE DUOS inAIR WIRELESS TRANSMITTER

**05**

Select the *Port name* of the device.<sup>3</sup>



**06**

Remove the cable from *DUOS inAIR Wireless Transmitter* side and reinsert it. This will access the device's configuration input window during 10 seconds.




<sup>3</sup> You can check the device port name in the Device Manager menu in the Windows operating system.

step  
**02**

**CONNECT AND CONFIGURE DUOS inAIR WIRELESS TRANSMITTER**


**07**

Click on *Connect* (🔌) button to enter configuration mode. These configurations are read automatically.



The status string at the bottom of the software window gives feedback on reading operations.

In configuration mode, *DUOS inAIR Wireless Transmitter* activates 4 LEDs: 2 blue LEDs flashes, red and green LEDs remains active and steady.



**NOTE:**

After reinserting the cable, you have 10 seconds to enter configuration mode by clicking on *Connect* (🔌) button, while blue LEDs flashes slowly.

When the 10 seconds window have been exceeded, blue LEDs are steady and it is no longer possible to enter configuration mode.

In that case, the cable must be removed from the transmitter and reinserted - step 3.

step

# 02


## CONNECT AND CONFIGURE DUOS inAIR WIRELESS TRANSMITTER

08

Configure *Wireless Network ID* and *Wireless Channel* previously obtained from the *Gateway*. The wireless connection between both devices is ensured by *Wireless Network ID* and *Wireless Channel* parameters.


Ensure that *Transmitter ID* is unique in the network. Each device must have a different *Transmitter ID*. Change it (if necessary) and take note to view the data later.

Click on *Write* button to update settings to the *Transmitter*.




**09**

Click on the *Configuration Mode* (🔗) button to exit setup and start the equipment in normal operation mode.




After this procedure:

- The *Transmitter* awaits connection to the *Gateway*, when only the red LED flashes;



- The *Transmitter* is connected via wireless and its data is available in the *Gateway*, when the red and green LEDs flash.



**NOTE:**

If the green LED does not flash, communication has not been established. Make sure that the devices are at a distance of at least 3 meters, or remove the antenna from the gateway (in case both devices are near each other). The *Transmitter LEDs* remain active during 1 minute. After this period, all LEDs shut down in order to optimise battery life.


To reset the transmitter, the batteries should be removed, during - at least - 50 seconds (in sleep mode) or instead, as the transmitter has a magnetic switch, a magnet can be used to reset it by passing the magnet close to the transmitter's front side in the blue LED's area.

step  
**03**

**CHECK WIRELESS COMMUNICATION BETWEEN DUOS TRANSMITTER AND GATEWAY**

**01**

Place the two windows of Tekon Configurator software devices side by side, in order to analyse communication between both devices.



**02**


Select the configured *Transmitter ID* in the *Gateway* window. After this, it is possible to access the address window of the *Transmitter* in analysis.

The communication between devices is successful when the *Communication Period* field is in compliance with its duration cycle. Therefore, as soon as the cycle duration has finished, it will turn back to 0.

Communication does not occur if the *Elapsed Time* field presents a higher value than the *Communication Period* field.

In the following example, it was established that the temperature monitoring cycle (or *Communication Period*) is 10 seconds. Therefore, the *Elapsed Time* field will turn back to 0 as soon as it reaches 10 seconds and the analysed parameters (in this case, the temperature) will be updated in accordance with ambient conditions.

You can define the communication period of the *Transmitter* in the write field by clicking on the *register* (  ) button.



step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER

**01**

Connect the antenna to the *Repeater*.




**02**

Connect *DUOS RS485-USB* cable to the computer and then to *Repeater*.



Check the device connection through the LEDs indication.




step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER


### 03

Open *TekOn Configurator Software* and select the menu *DUOS >> Repeater*.



### 04

Click on *Refresh Serial Ports* button.




step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER

### 05

Select *Port name* of the device.<sup>4</sup>



### 06

Remove the cable from *Repeater* and reinsert it. After reinserting the cable you have 10 seconds to enter configuration mode by clicking on the *Connect* (🔌) button, while the blue LED flashes slowly.



**NOTE:**

When the 10 seconds have been exceeded, the blue LED remains steady and it is no longer possible to enter *Configuration mode*. In that case, the cable must be removed from Repeater and reinserted.

<sup>4</sup> You can check the device port name in the Device Manager menu in the Windows operating system.



step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER

07

Click on the *Connect* (🔌) button to verify the device's configuration data.



- ▶ LED switched off
- - - - -▶ LED flashes slowly
- · - · -▶ LED flashes quickly
- ▶ LED switched on (red/green LED)


step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER

08

Make sure that *Wireless Network ID* and *Wireless Channel* in the *Repeater* window have the same values as the ones that were obtained in the *Gateway* configuration window.




**NOTE:**

If there is more than one *Repeater* in the network, make sure that the *Repeater ID* is unique in order to avoid network conflict.

09

Change configuration fields (if necessary) and click on *Write* (📄) button to update the *Repeater ID* parameter.




step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER

10

Click on the *Configuration Mode* (🌐) button to exit the setup programme.




**NOTE:**

In order to establish communication between the Repeater and the Gateway, make sure that both devices are at a distance of at least 3 meters or remove the antenna from the repeater (in case both devices are near each other). These procedures will guarantee communication quality.

At this moment, it is possible to check if:

- The *Repeater* is trying to connect to the network when the red LED flashes every second.




- LED flashes slowly
- 1** --- Red LED flashes until communication can be established

step

# 04

## CONNECT AND CONFIGURE DUOS WIRELESS REPEATER

- The *Repeater* is connected to the wireless network when red and green LEDs flash.



LED switches on and remains steady

**1** Red/green LED flashes as soon as connection between the devices has been established.

step

# 05

## CONNECT DUOS WIRELESS IoT GATEWAY

**01**

Change the switch pin to *Normal Mode*.

Plug the ethernet cable that follows with your gateway to the device's input and to your network.



**02**

Your **DUOS IoT GATEWAY** physical connection should look like this.



### WIFI




The access through this interface only allows the configuration and consultation of **DUOS IoT GATEWAY**. Unable to send data to the cloud over this channel.

The **DUOS IoT GATEWAY** appear with an SSID with the following configuration *WGW4IoT-hostname*. By default, the devices follow with the SSID *WGW4IoT-<serialnumber>*

**03**

Connect to the wifi network that comes from your gateway.

Use the password *bresimar* to login.



step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**DUOS IoT GATEWAY** has a fixed IP address assigned to be accessed via mobile phone, tablet or pc (through Wi-Fi). The interface designed to interact with the device can be accessed through its fixed IP ([192.168.128.1](http://192.168.128.1)) or its SSID address (<http://Tekon>). The factory-defined and configurable access data are:

- **Login:** admin
- **Password:** admin



**NOTE:**

This password and username must be changed to improve the security level.



**NOTE:**

After a power-on cycle, the first access to the gateway may have a long time waiting time and should not be confused with a lack of response.



**NOTE:**

SSID address access is only possible until it is changed. After the change, you must access by the user-defined SSID.

**04**

Check your network credentials. Click on [Settings](#) >> [IP Network](#) tab.

By default, your gateway has a static ethernet IP address for the network (192.168.100.1). You can choose to keep this IP address or activate the DHCP feature to be assigned a dynamic IP address by the network.

The screenshot displays the 'Settings' page of the Tekon IoT Gateway. The 'Network' tab is selected. Under 'IP Network Table', the following table is visible:


Interface	DHCP	IP Address	Netmask	Gateway	MAC Address	
eth0	Disabled	192.168.100.1	255.255.255.0	192.168.0.250	40 a3 60 c2 1c 4c	<input checked="" type="checkbox"/> Manage
lo	Disabled	127.0.0.1	255.0.0.0		00:00:00:00:00:00	
ra0	Disabled	192.168.128.1	255.205.255.0		40 a3 60 c2 1c 4a	

Below the table, the 'NTP' section shows 'NTP Peer' set to 'pt.pool.ntp.org'. The 'Proxy Configuration' section has empty fields for 'HTTP Proxy' and 'HTTPS Proxy'.

step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY


**05**

To enable the option to get an dynamic IP address assigned by your network, click on *Manage* button.



**06**

A pop-up window will show up. Click on the validation box, next to the *DHCP* label to enable the option and click on the *Update* button to save the changes. You will be redirected to the previous page.



Write down the IP address of your device's ethernet port. It will be needed later.

step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**CONFIGURE A PROXY SERVER (OPTIONAL)**

**07**

You can configure a proxy server to your gateway. Go to the [Settings](#) >> [Network](#) >> [Proxy Configuration](#). Complete the [HTTP Proxy](#) and [HTTPS Proxy](#) fields with the [correct address](#) of your proxy server.

Click on the [Update](#) button to save the changes.

Interface	DHCP	IP Address	Netmask	Gateway	MAC Address	
eth0	Disabled	192.168.100.1	255.255.255.0	192.168.0.250	40:a3:6b:c2:1c:4c	<a href="#">Manage</a>
lo	Disabled	127.0.0.1	255.0.0.0		00:00:00:00:00:00	
ra0	Disabled	192.168.128.1	255.255.255.0		40:a3:6b:c2:1c:4a	

Showing 1 to 3 of 3 entries: [Previous](#) **1** [Next](#)

**NTP**

NTP Peer:

[Test](#) [Update](#)

**Proxy Configuration**

HTTP Proxy:

HTTPS Proxy:

[Update](#)

**NOTE:**  The proxy address must consider the full path configuration like in the example: 'http://my.proxy.com:9000' or 'https://my.secure.proxy.com:9000'

step

05

CONNECT DUOS WIRELESS IoT GATEWAY


## ACCESS TO DUOS GATEWAY IOT THROUGH ETHERNET

08

The connection to **DUOS IoT GATEWAY** through Ethernet is made using your web browser. You can access by the hostname (`http://<hostname>`) or via IP address (`http://<192.168.100.1>`).

The default login credentials are:

- **Login:** admin
- **Password:** admin



### NOTE:


DUOS IoT GATEWAY access credentials displayed by default can be edited in *Settings* » *Users* menu.

step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**TRANSMITTER ACTIVATION**

**09**


At login, the graphical interface displays the transmitters that are connected to the network. The first presentation of the devices connected to the network is through a vertical listing (1). To get an overview of your system, at the bottom of the main page, you will find information about the activity and links established (2).



The transmitters are listed in ascending numerical order. By default, the name appears with “N/A” until it is edited and reset. The *Hub ID* field match to the *Transmitter ID* field defined in *Tekon Configurator* over the transmitter configuration.

**10**

Click on the *Hub ID* field of the transmitter to activate. You will be redirected to the selected transmitter page, select the *Properties* tab (1), in the *Status* property, choose the *Active* state (2) and click on the *Update* button (3) to save the change.



step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY



The transmitter is activated.  
Transmitter information available for all the interfaces.



If you would like to send data from this transmitter to Tekon IoT Platform, set the *Synchronize to Cloud* field to *On* mode and save the changes. We will return to this subject shortly.

**11**

In the "Properties" tab, fill in the fields:

- **"Name"** and **"Description"** according to your preference;
- **"Refresh Time"** according to the intended transmitter communication period;

Save the changes in the *Update* button.

Tekon IoT Gateway | HOME | SENSOR NETWORK | SETTINGS | ADMIN

### Sensor Hub - 1

Measurements | Properties | Modbus

Properties

Name	DUOS inAirQuality
System Id	1:0:0:0
Network Id	1:0:0:1
Firmware Version	1.0.0
Communication Period (seconds)	10
Status	ACTIVE
Description	
Synchronize to Cloud	Off

Delete Update




The transmitter is configured.

step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**CONNECTION TO TEKON IOT PLATFORM**


**12**

In the DUOS IoT GATEWAY page, go to *Settings* >> *Cloud Services*.



**13**


In a new browser page, access your Tekon IoT Platform and go to *Settings* >> *Administration*.



step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**14**


Click on the view option to see the *gateway* user data and copy the API key.



**15**

In the **DUOS IoT GATEWAY** page, fill in the fields:  
 - **“Server URL”** with your Tekon IoT Platform address;  
 - **“API Key”** with the Api key previously copied;

Change the *Status* field value to *On*.






step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**ATTACH TRANSMITTER DATA TO TEKON IOT PLATFORM**

**17**

Access to your Tekon IoT Platform, click at the *Datasources* menu and the button (✎) to edit the datasource where you want to send the transmitter data.




**18**

Copy the API key from the datasource and go back to your DUOS IoT GATEWAY page. On the page, select the transmitter you want to match, fill in the *API Key* field with the copied value.

You can test and validate the credentials, as explained in the step 16.

Click on *Update* button to save the changes.



step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY



**NOTE:**

The message “Cloud Synchronization On” will only be visible if you have activated the option “Synchronize to Cloud” in the “TRANSMITTER ACTIVATION” step to activate your transmitter. If you did not perform the validation, the message “Cloud Synchronization Off” will be displayed in the “Status” field.



Your transmitter is now connected to your Tekon IoT Platform.



**NOTE:**

Perform a reboot in the gateway. Remove the *DUOS RS485-USB* cable on the gateway port and reconnect it.

**VERIFY COMMUNICATION WITH TEKON IOT PLATFORM**

**19**

To verify if the information acquired by the transmitter is effectively reaching your [Tekon IoT Platform](#), click on the [Datasources](#) menu and check the date of the latest communication between the platform and the transmitter. This log will tell you if the communication process is on or not.

Datasource *	Date *	Communication *	Variable *	Actions
DUOS-HYGRDTEMP-1	11/16/2021 3:56:47 PM	WITHOUT ALARMS	WITHOUT ALARMS	[Icons]
DUOS-HYGRDTEMP-2	11/16/2021 3:53:12 PM	WITHOUT ALARMS	WITHOUT ALARMS	[Icons]
DUOS-HYGRDTEMP-3	11/16/2021 3:33:02 PM	WITHOUT ALARMS	WITHOUT ALARMS	[Icons]
Data In Air Quality	11/16/2021 5:51:12 PM	OK	OK	[Icons]
HYGRDTEMP-DIL - 1220500002	03/13/2018 1:33:30 PM	WITHOUT ALARMS	OK	[Icons]
TEMP-DC - 1220600006	03/13/2018 1:28:36 PM	WITHOUT ALARMS	OK	[Icons]


step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY

**DATA COMMUNICATION OVER MODBUS TCP/IP**

**20**

You can pre-check the **DUOS IoT GATEWAY** graphical interface of Modbus TCP/IP communication. In each transmitter you can analyse different common parameters in modbus communications.


Click on the transmitter / hub you want to analyze and select the **Modbus Holding Registers** tab.



**21**

In this page, you have the selected transmitter modbus scheme.

- (1): variable names;
- (2): current value recorded;
- (3): modbus address;
- (4): register value;
- (5): register type;
- (6): register data type;



step  
**05** | CONNECT DUOS WIRELESS IoT GATEWAY



**NOTE:**

In this example we used the transmitter / hub 1. The first modbus address of its variables starts at 0. To find the modbus address calculation formula defined for DUOS IoT GATEWAY, please refer the datasheet on Tekon Electronics website.



To access to the records via [Modbus TCP/IP](#) in real time, you must use a program developed for this purpose, external to Tekon Electronics.

**Configuration of Modbus TCP/IP:**

- [DUOS IoT GATEWAY](#) IP;
- Port: 1502;

**REVISION HISTORY**

**VERSION**

E01B

© BRESIMAR AUTOMAÇÃO, S.A.  
All rights reserved.


The contents of this document (texts, images, brands, corporate image, trade name, designs, methodological and product descriptions, among others), as well as its structure and design, are owned by Bresimar Automação, SA (herein in referred to as Bresimar) or, it has legitimacy for its use, being strictly prohibited the modification, exploitation, reproduction, communication to third parties or distribution of all or part of the contents of this document, without the prior express written consent of Bresimar .

Bresimar will not be liable for any claim, loss or damages resulting from or arising from a cause over which Bresimar has no control, whether by acts or omissions, breach of contract or non-compliance with applicable laws by the Supplier , as well as incidents caused by the client's systems.

**TEKON ELECTRONICS**  
a brand of Bresimar Automação S.A.

Avenida Europa, 460  
Quinta do Simão  
3800-230 Aveiro  
PORTUGAL

P.: +351 234 303 320  
M.: +351 933 033 250  
E.: sales@tekonelectronics.com



Cofinanciado por:



UNIÃO EUROPEIA  
Fundo Europeu  
de Desenvolvimento Regional