

TEMPERATURE WIRELESS TRANSMITTER PLUS TWPH-1UT



The Wireless Temperature Transmitter TWPH-1UT is specifically designed to meet the most rigorous requirements of temperature monitoring in industrial process environments. In its high power mode it can communicate over a long distance range.

The Wireless Temperature Transmitter TWPH-1UT accepts the most commonly used temperature sensors.

Its dual operating mode allows it to work as an end device for temperature measure and as a repeater to improve network redundancy.

Dimensions: 45 mm x 23 mm Weight: Approx. 50g Material: Nylon 66 Protection Index: IP40

KEY FEATURES

ULTRA LOW POWER MODE

UP TO 4 KM COMMUNICATION DISTANCE (LoS)

WIRELESS SITE SURVEY FUNCTION FOR EASY INSTALLATION AND FAST DEVELOPMENT

WIDE RANGE SUPPLY VOLTAGE FROM 5 TO 24V DC

MULTI-HOP MESH NETWORK WITH SELF-FORMING, SELF-HEALING, SELF-OPTIMIZING FEATURES

UNIVERSAL SENSOR INPUT PT100, C, J, K, N, R, S, T

6 STATUS LEDS

DS_PLUS_TWPH-1UT_E018

TEKONELECTRONICS.COM



TECHNICAL SPECIFICATIONS

868MHZ	915MHZ
Up to 4	4 Km LoS
868 to 869 MHz	902 to 928 MHz ³
16	50 ⁴
-97 to -110 dBm	
25 to 27 dBm	8 to 27 dBm
19 to 76,8 kbit/s	
AES 128(Advanced Encryption Standard)	
GFSK	
SMB	
Articulated dipole antenna	
50	
	Up to 4 868 to 869 MHz 16 -97 to 4 25 to 27 dBm 19 to 7 AES 128(Advanced G Articulated of

WIRELESS NETWORK	
Maximum devices	55
Maximum hops	13
Communication period	1 to 43200 seconds (configurable)

INPUT RESISTANCE THERMOMETER (RTD)	
Measured variable	Temperature
Sensor type	PT100
Units	٦٥
Connection	1 Resistance thermometer (RTD) in 2-wire, 3-wire or 4-wire system
Sensor current	200µA
Open-circuit monitoring	Always active (cannot be disabled)
Short-circuit monitoring	Always active (cannot be disabled)
Measuring range	See "Digital measuring accuracy" table
Cable resistance per wire (max.)	50 Ω

INPUT THERMOCOUPLES (TC)	
Measured variable	Temperature
Sensor type	Thermocouples: C, J, K, N, R, S, T
Units	٦°
Connection	1 Thermocouple
Open-circuit monitoring	Always active (cannot be disabled)
Short-circuit monitoring	Not available
Cold junction compensation (CJC)	Integrated resistance thermometer
Measuring range	See "Digital measuring accuracy" table

POWER SUPPLY	
Voltage Range	5 to 24V DC
Measurement accuracy	± 50mV
Power consumption (sleep)	22 µA @ 12V DC

TEMPERATURE WIRELESS TRANSMITTER TWPH-1UT



Protection	Against reversed polarity	
MEASUREMENT ACCURACY		
Reference conditions		
Power supply	12V DC \pm 1%	
Ambient temperature	23℃	
Digital measuring errors	See table "Digital measuring accuracy" table	
Internal cold junction		
Ассигасу	< ± 0,50 °C	
Resolution	0,01 °C	
Influence of ambient temperature		
on RTD measurement	< ± 0,001 °C / °C	
on thermocouple	Thermocouples C, J, K, N, T: $\le \pm 0,005 \text{ °C} / \text{ °C}$ Thermocouple R: $\le \pm 0,010 \text{ °C} / \text{ °C}$ Thermocouple S: $\le \pm 0,2 \text{ °C} / \text{ °C}$	
EMC - immunity influence (IEC 61326-1)	[To Be Defined]	
OPERATING ENVIRONMENT		

Ambient temperature range	-40 to 80°C
Storage temperature range	-40 to 80°C
Relative humidity	≤95%, without condensation

FACTORY DEFAULT SETTINGS	868MHZ	915MHZ
Frequency	869,525MHz	915,000MHz
Radio transmit power		27dBm
Radio transmission rate	7	6,8kbit/s
Wireless channel	13 26	
Wireless network ID	13042017	
Communication period	10 seconds	
Reconnection period	30 minutes	
Gateway modbus index	1	
Operating mode	End Device	
Transmitter description	TekOnElectronics	
Sensor type	PT100 3W	

CASING	
Material	Nylon 66
Weight	Approx. 50g
Dimensions	See "Dimensional drawings"
Cross section	2,5 mm
Protection type	IP40

CERTIFICATIONS AND APPROVALS

EN 61326-1 - Class B - Industrial Requirements EN 300 220-2 V3.1.1 EN 301 489-1 V2.2.1



EN 60950-1:206

EN 61326-1:2013

ETSI EN 301 489-1 V1.9.2

¹ Range depends on the RF propagation environment and Line of Sight (LoS). Always verify your wireless network's range by performing a Site Survey. ² Dependent on radio channel selection.

³ In some countries, the frequency band admitted is not so extended as the default range.

⁴The radio frequencies admitted in Australia are available from channel 26 to channel 50.

DIGITAL MEASURING ACCURACY			
RESISTANCE THERMOMETER (RTD)			
Sensor	Range °C	Accuracy °C	Resolution °C
PT100	-210 to 850	< ± 0,2	0,05

THERMOCOUPLES (TC)			
Sensor	Range °C	Accuracy ⁰C	Resolution °C
С	0 to 2300	< ± 1,0	0,400
J	-210 to 1200	< ± 1,0	0,077
К	-270 to 1370	< ± 1,0	0,098
Ν	-270 to 1270	< ± 1,0	0,151
R	-50 to 1760	< ± 1,2	0,189
S	-50 to 1760	< ± 2,0	0,185
Т	-270 to 400	< ± 1,0	0,026

TECHNICAL DRAWINGS AND INFORMATION

ELECTRICAL CONNECTIONS

RESISTANCE THERMOMETER



THERMOCOUPLE

POWER SUPPLY

+ -

0/0

0000

4

3(

 $\circ \bigcirc \circ$

C



* The 2-wire connection requires an electrical connection between screw 5 and screw 6

TEMPERATURE WIRELESS TRANSMITTER TWPH-1UT



DIMENSIONAL DRAWINGS





OPERATIONS BUTTON ACTIONS



OPERATION	ACTION*	DESCRIPTION
SITE SURVEY	PRESS 3 seconds to enter/exit	 Transmitter will perform a site survey; Red LED and green LED stay on; RSSI power level is indicated by the 4 blue LEDs;
LOAD DEFAULT SETTINGS	PRESS 10 seconds	- Transmitter will load the default settings; - The 4 blue LEDs will light up gradually until the operation be completed;

STATUS LED



GREEN AND RED LEDS	BLUE LEDS	DESCRIPTION	
ON	BLINK EVERY SECOND	- Transmitter in Configuration Mode;	
RED LED BLINK	OFF	- Quit Configuration Mode and starting connection to the gateway;	
FLASH ALTERNATELY 1 MINUTE	OFF	- Connected to the gateway; - After 1 minute, LEDs go off;	
OFF	OFF	- Transmitter in Sleep/Normal Mode;	
RED LED BLINK OVER 1 MINUTE	OFF	 Transmitter did not connect to the gateway; It will continue to try to establish communication; 	

* Operations button has only two possible actions. Any action beside the documented will have no effect on the transmitter



RELATED PRODUCTS



REVISION HISTORY

VERSION	
E01B	Inclusion of information about the frequency range used in Australia.
E01C	Revision of "Certifications and Approvals" table.
E01D	Inclusion of Reconnection Period on "Factory Default Settings Table"

© BRESIMAR AUTOMAÇÃO, S.A. All rights reserved.

The contents of this document (texts, images, brands, corporate image, trade name, designs, methodological and product descriptions, among others), as well as its structure and design, are owned by Bresimar Automação, SA (herein in referred to as Bresimar) or, it has legitimacy for its use, being strictly prohibited the modification, exploitation, reproduction, communication to third parties or distribution of all or part of the contents of this document, without the prior express written consent of Bresimar.

Bresimar will not be liable for any claim, loss or damages resulting from or arising from a cause over which Bresimar has no control, whether by acts or omissions, breach of contract or non-compliance with applicable laws by the Supplier, as well as incidents caused by the client's systems.

TEKON ELECTRONICS a brand of Bresimar Automação S.A.

Quinta do Simão 3800-230 Aveiro PORTUGAL

P.: +351 234 303 320 M.: +351 933 033 250 E.: sales@tekonelectronics.com



UNIÃO EUROPEIA Fundo Europeu de Desenvolvimento Regional